


R410A MULTI SPLIT SERIES ROOM AIR CONDITIONER

INDOOR UNIT INSTALLATION MANUAL



AF092XCERA

AF122XCERA

No.0010578129

A

- Please read this manual carefully before using this air conditioner.
- Please keep this manual safely for future use.



Большая библиотека технической документации
<http://splitoff.ru/tehn-doc.html>
каталоги, инструкции, сервисные мануалы, схемы.

■ Contents

Cautions	1-4
Parts and Functions	5-6
Operation hints	7
Maintenance	8
Trouble shooting	9
Installation Manual of Room Air Conditioner	10-16

■ Cautions

Disposal of the old air conditioner

Before disposing an old air conditioner that goes out of use, please make sure it's inoperative and safe.

It must be noticed that air conditioner system contains refrigerants, which require specialized waste disposal. The valuable materials contained in an air conditioner can be recycled. Contact your local waste disposal center, relevant waste disposal center, and contribute to environmental awareness by insisting on an appropriate, anti-pollution method of disposal.

Safety Instructions and Warnings

Before starting the air conditioner, read the information and safety instructions carefully. Unplug the air conditioner.

The manufacturer does not accept responsibility for damage to the air conditioner. Contact your local waste disposal center for more information.

- Damaged air conditioners are not to be put into operation. In case of doubt, consult your supplier.

- Use of the air conditioner is to be carried out in accordance with the instructions.
- Installation shall be done by professional people.

Disposal of the packaging of your new air conditioner

All the packaging materials employed in the package of your new air conditioner may be recycled.

The cardboard box may be broken or cut into smaller pieces, and given to a waste paper disposal service. The wrapping bag made of polyethylene and the polyethylene foam pads contain no fluorochloro hydrocarbon.

All these valuable materials may be taken to a waste collecting center and used again after adequate recycling.

Consult your local authorities for the name and address of the waste materials collecting centers and waste paper disposal service.

- For the purpose of the safety, the air conditioner must be unplugged before opening the inlet grill.

Always remember to unplug the air conditioner before opening inlet grill. Never unplug the power cord. Always grip plug firmly and pull straight out from the outlet.

All electrical repairs must be carried out by qualified electricians. Inadequate repairs may result in a major source of danger for the user of the air conditioner.

Do not damage any parts of the air conditioner by scraping the coatings off the surfaces. If the refrigerant spurts out and gets into eyes,

-

■ Cautions

• Do not obstruct or cover the ventilation grille of the air conditioner. Do not put fingers or any other things into the inlet/outlet.

Do not allow children to play with the air conditioner. In no case should children be allowed to

Model	power cable	Communication cable
AF072XCERA	H05RN-F 3G (1-2.5)mm ²	H05RN-F 2X(0.75-1.5)mm ²
AF122XCERA	H05RN-F 3G (1-2.5)mm ²	H05RN-F 2X(0.75-1.5)mm ²

Specifications

- The refrigerating circuit is leak-proof.

The machine is adaptive in following situation

1. Applicable ambient temperature range:

			Rated	Maximum	Minimum
Cooling	Indoor	DB °C	27	32	18
		WB °C	19	23	14
	outdoor	DB °C	35	43	10
		WB °C	24	26	6
Heating	Indoor	DB °C	20	27	15
		WB °C	14.5	--	--
	outdoor	DB °C	7	24	-15
		WB °C	6	18	--

2. If the power supply cord is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person.

3. If the fuse of indoor unit on PC board is broken, please change it with the type of T3.15A/250VAC.

4. The wiring method should be in line with the local wiring standard.

5. The power cable and connecting cable are selfprovided.

The requirement of the communication cable:

6. The waste battery should be disposed properly.

7. The appliance is not intended for use by young children or infirm persons without supervision.

8. Young children should be supervised to ensure that they do not play with the

9. A breaker should be used in the circuits, which should be all-pole cut off and the distance between its two contacts should

10. The power plug and connecting cable must have acquired the local attestation.

■ Cautions

Safety Instruction

- Please read the following Safety Instructions carefully prior to use.
- The instructions are classified into two levels, WARNING and CAUTION according to the seriousness of possible risks and damages as follows. Compliance to the instructions are strict.

Installation


⚠ WARNING

Please call Sales/Service Shop for the Installation.

Do not attempt to install the air conditioner by yourself because improper works may cause electric shock, fire, water leakage.




Installation in an inadequate place may cause accidents. Do not install in the following place.


⚠ CAUTION

<p>Connect the earth cable.</p> <p></p> <p>STRICT ENFORCEMENT</p>	<p>Do not install in the place where there is any possibility of inflammable gas leakage around the unit.</p> <p></p> <p>PROHIBITION</p>	<p>Do not get the unit exposed to vapor or oil steam.</p> <p></p> <p>PROHIBITION</p>	<p>Check proper installation of the drainage securely</p> <p></p> <p>STRICT ENFORCEMENT</p>
<p>Use fuse with specified capacity. Replacement with steel or copper wires are absolutely prohibited.</p> <p></p> <p></p>		<p>Grounding wire should not be connected to that of</p>	

■ Cautions


Use of Air Conditioner

⚠ WARNING		
<p>When abnormality such as burnt-smell found, immediately stop the operation button and contact sales shop.</p>		<p>Use an exclusive power source with a circuit breaker.</p>
 OFF 	 STRICT ENFORCEMENT	
<p>Connect power supply cord to the outlet completely.</p>	<p>After installed, the unit shall be tested for electric leakage.</p>	<p>Do not use power supply cord extended or connected in halfway.</p>
 STRICT ENFORCEMENT	 STRICT ENFORCEMENT	 PROHIBITION
<p>Do not use power supply cord in a bundle.</p>	<p>Take care not to damage the power supply cord.</p>	<p>Do not insert objects into the air inlet or outlet.</p>
 PROHIBITION	 PROHIBITION	 PROHIBITION
<p>Do not start or stop the operation by disconnecting the power supply cord carelessly, especially at infants or the aged.</p>	<p>Do not channel the air flow directly towards people, especially at infants or the aged.</p>	<p>Do not try to repair or reconstruct by yourself.</p>
 PROHIBITION	 PROHIBITION	

⚠ CAUTION		
<p>Do not use for the purpose of storage of food, art work, precise equipment, etc. when gas is running.</p>	<p>Take fresh air occasionally especially when gas is running.</p>	<p>Do not operate the switch with wet hands at the same time.</p>
 PROHIBITION	 STRICT ENFORCEMENT	 PROHIBITION
<p>Do not install the unit near a fireplace or other heating apparatus.</p>	<p>Check good condition of the installation stand.</p>	<p>Do not pour water onto the unit for cleaning.</p>
 PROHIBITION	 PROHIBITION	 PROHIBITION
<p>Do not place animals or plants in the direct path of the air flow.</p>	<p>Do not place any objects on or climb on the unit.</p>	<p>Do not place flower vase or water containers on the top of the unit.</p>
 PROHIBITION	 PROHIBITION	 PROHIBITION

■ Parts and Functions

Indoor unit



"POWER" lamp (Green)

It lights up when the indoor Unit is started.

"TIMER" lamp (Yellow)

It lights up when "TIMER" function is acticated for programmed start/stop.


"RUN" lamp (Red)

It lights up when the compressor (Outdoor Unit) is operating.

⚠ WARNING

Before opening the frontal grille, stop the air conditioner and disconnect the appliance. Never touch the metal pates inside the unit in order to avoid injuries.

■ Parts and Functions



Remote controller's infrared receiver

It allows the reception of signals sent by the remote controller. If the signal is received, the unit emits a "bip" confirmation sound.

ON/OFF button



When the remote controller is not available, press this button to start the unit. The fan speed will be set to "AUTO". Press the button again to stop the unit.

Air outlet selector

It allows to select the airflow direction:
upwards and downwards at the same time:



In fan mode, press SLEEP button 6 times continuously, indoor buzzer sounds 2 times.
upwards only:

In fan mode, press SLEEP button 6 times continuously, indoor buzzer sounds 1 times.



Factory default (recommended)

The unit automatically adjusts the airflow direction on the basis of the operation conditions and settings carried out by the user.



Alternative optional setting:

The unit emits air from the upper outlet only.


■ Operation hints

EMERGENCY OPERATION

Carry out this operation only when the remote controller is defective or lost.

Unit start

When the emergency operation switch is pressed, a sound you can hear, which means the start of this operation.



Follow the requirements below.

Room temperature	Designated temperature	Timer mode	Air flow speed	Operation mode
≥ 24°C	24°C	None	AUTO	COOL
< 24°C	24°C	None	AUTO	HEAT

Unit stop (to cancel emergency operation)

Press the emergency switch and hear a sound, the unit stops.

Power failure resume (please set and apply as necessary)With setting of power failure resume

Setting method:

with ON of remote controller (except TIMER and FAN),repeatedly press SLEEP button 10 times in 5 seconds,after 4 Beep from the buzzer,the unit comes into power failure resume mode.


To cancel:

press SLEEP button continuously 10 times in 5 seconds,the buzzer sounds Beep twice and power failure resume function is canceled.

Note:When sudden power failure happens during unit operation in power failure resumemode, the power supply in case that the unit automatically resume operation when power is re-supplied, or press ON/OFFto turn off the unit when power resumes.

Maintenance

Cleaning of the unit


Turn off the power switch	Do not touch with wet hand	Do not clean with hot water or solvent
		

Take off the air inlet grill

First switch off the power supply, take off the screw cap, loosen the screw with cross screwdriver.

Clean the filter

Use water or vacuum cleaner to remove dust. If it is too dirt, clean with detergent or neutral soap water. Rinsing with fresh water, dry the filter and re-assemble.




Caution: Do not wash filter in hot water above 40°C, which will damage the filter. Do carefully wipe the filter.



Clean the indoor(outdoor) unit

Clean with warm cloth or neutral detergent, then wipe away moisture with dry cloth. Do not use too hot water (above 40°C), which will cause discoloration or deformation. Do not use pesticide or other chemical detergents.




Maintenance at the end of application season

On a fine day, unit shall be started and operate in FAN mode for about half a day until the inside of the unit becomes thoroughly dry.

Turn off the unit operation switch and power on/off. Otherwise, there will be some electricity consumption even the unit is in stop status.

Clean the filter and indoor, cover the units well.



Maintenance before beginning of application season

Check there are no obstacles in the air inlet and outlet to avoid impairing of working efficiency. Please do attach the air filter to ensure the filters not soiled. Otherwise, dirt will come

■ Trouble shooting

Before asking for service, check the following first.

	Phenomenon	Cause or check points
Normal Performance inspection	<p>The system does not restart immediately.</p> 	<ul style="list-style-type: none"> • When unit is stopped, it won't restart immediately until 3 minutes have elapsed to protect the system. When the electric plug is pulled • for 3 minutes to protect the air conditioner.
	<p>Noise is heard:</p> 	<ul style="list-style-type: none"> • During unit operation or at stop, a swishing or gurgling noise may be heard. At first 2-3 minutes after unit start, this noise is more noticeable. (This noise is generated by refrigerant flowing in the system.) • During unit operation, a cracking noise may be heard. This noise is generated by the casing expanding or shrinking because of temperature changes. • Should there be a big noise from air flow in unit operation, air filter may be too dirty.
	<p>Smells are generated.</p>	<ul style="list-style-type: none"> • This is because the system circulates smells from the interior air such as the smell of furniture, cigarettes.
	<p>Mist or steam are blown out.</p>	<ul style="list-style-type: none"> • During COOL or DRY operation, indoor unit may blow out mist. This is due to the sudden cooling of indoor air.
Multiple check	<p>Does not work at all.</p>	<ul style="list-style-type: none"> • Is power plug inserted? • Is there a power failure? • Is fuse blown out?
	<p>Poor cooling</p> 	<ul style="list-style-type: none"> • Is the air filter dirty? Normally it should be cleaned every 15 days. Are there any obstacles before in • Are there some doors or windows left open? • Is there any direct sunlight through the window during the cooling operation? (Use curtain) • Are there too much heat sources or too many people in the room during cooling operation? •

Installation Manual of Room Air Conditioner




Fig1




Fig2




Fig3

Tool necessary

1. Screw driver
2. Hacksaw
3. 70mm dia.hole core drill
4. Spanner(dia. 17,27mm)
5. Spanner(14,17,27mm)
6. Pipe cutter
7. Flaring tool
8. Knife
9. Nipper
10. Gas leakage detector or soap water
11. Measuring tape
12. Reamer
13. Refrigerant oil

Installation of indoor unit

selection of installation place

- Place where it is easy to route drainage pipe and outdoor piping.
- Place ,away from heat source and with less direct sunlight.
- Place where cool and warm air could be delivered enough space around the unit.Place ,robust not can
- body can be supported sufficiently.

To prevent interference, place it at least 1m

- away from other electric machines, such as TV set, radio.

Installing

According to the dimension of the figure 2 shown, nail two cement steel nails on the wall,Keep 2~3mm out.then hang the back of

- the unit on them.

There must be no gap between the indoor unit and wall.

Remove the front panel,then use two

- expansible screws to fix the unit on the floor. As figure 3 shown.

- Once refrigerant piping and drain piping connections are complete,fill the gap of the throught hole with putty.

- Attach the front panel and front grille in their original positions once all connections are complete.


•

■ Installation Manual of Room Air Conditioner

Fixing of the unit

1. Position of the wall hole


Wall hole should be decided according to installation place and piping direction. (refer to installation drawings).



2. Making a wall hole Drill a hole of 120X70mm dia. with a little slope towards outside.


3. Piping connection

(1) Schematic diagram for unit connection



(2) Connection pipe dimensions:


Pipe Value		Torque
Liquid	6.35mm	11.8 N.m
Gas	9.52mm	40 N.m



- Apply and tighten the nut.

(3) Cautions for pipe connection

- Pipes free from twists, deformation, water, dust. Dedicated tools for each R407C and R410A should be used and stored separately.
- Optimized radii of bends
- Insulation to be applied on all gaseous pipes
- Flared section free from cracks



Threads on the pipes may be damaged when tightening if the pipes are not well aligned.

(4) Pipe connection process

Apply refrigeration oil on the end of the pipe to be connected and on the flared section. Align the pipes to be connected and tighten the nut. (See the figure)
Ensure that no foreign articles enter into the pipes.

■ Installation Manual of Room Air Conditioner


Piping connection of the indoor unit

1. Arrangement of piping and drainage pipe

After opening inlet grill, you will see a control box.

Remove the cover before working.

Cut away, with a hammer or a saw, the lid for piping according to piping direction.



According to the piping method, connect the piping on indoor unit with union of connection pipe.

Arrange the piping as per the wall hole and bind drain hose connecting electric cable and piping together with polyethylene tape.

Insert the bound piping connecting electric cable and drain hoses through wall hole to connect with outdoor unit.

2. Arrangement drain hose

Drain hose shall be placed in under place.

There should be a slope when arrange drain hose. Avoid up and down waves in drain hose.

If humidity is high, drain pipe (especially in room and indoor unit) must be covered with installation material.

Electric wiring :

Process of wire connections

1. Loop terminal

After removing the screw, fix the wire ring on the screw, reinsert the screw into the block terminal and then tighten the screw.

2. Straight terminal

After loosening the screw, inset the wire end into the block terminal and then tighten the screw. Slightly pull the wire to see if it is tightly fixed.

3. Wire capping

After completion of connection, capping clips must be applied on the external sleeve of the wires.

■ Installation Manual of Room Air Conditioner


Others

1. Power supply requirements:

- Voltage: single-phase 1PH, 220-230V~, 50Hz
- Dedicated electrical cable should be installed by a qualified technician in accordance with the state regulation for electrical engineering.
- The power source must be grounded.
- A circuit breaker must be installed
- Electrical cables should be connected by "Y" method. Damaged or worn electrical cable must be replaced by authorized after sales agents.
- The power plug should be connected as follows: L for live line, N for neutral line and ⊕ for grounding.
- Connection parameters: H05RN-F 3G(1.0-1.5)mm²
- Signal parameters: H05RN-F 2x(0.75-1.5)mm² (Shielded wire)
- The signal wire must be shielded wire.
- Cables for power supply, connection and signals are prepared by the owner.

2. Piping cutting and flaring

Be sure to carry out deburring after cutting with a pipe cutter.
Insert flaring tool to make a flare.



Installation inspection and test run:

Please operate unit according to this Manual.


Items to be checked during test run. Please made a "√" in "□"

- Are there any gas leakage?
- How is insulation at piping connection carried out?
- Are electric wires of indoor and outdoor unit firmly inserted into terminal block?
- Is electric wiring of indoor and outdoor securely fixed?
- Is drainage securely carried out?
- Is earth line(grounding) securely connected?
- Is power supply voltage abided by the code?
- Is there any noise?
- Is control display normal?
- Is cooling operation normal?
- Is room temp. regulator normal?


■ Installation Manual of Room Air Conditioner

Wiring of indoor unit


- Remove air intake screen and take out the front wires.
- Connect the wires as specified in the above methods and diagrams for indoor unit and wire connections.
- Properly apply capping clips on the wires.
- Replace the air intake screen.
- Do not link the connecting and signal wire with the same cable, a snug space must be maintained between connecting and signal wires.
- Shield of the signal wire should be spot grounded.



Wiring diagram of loop terminals



Wiring connection:



⚠ WARNING

Incorrect address setting will cause abnormal to the system.

Communication cable must be use shielded type.

Incorrect address setting will cause abnormal to the system.and then put it down perpendicularly.

Signal connecting cable must be shielded type.The distance between the signal wires and th

■ Installation Manual of Room Air Conditioner

Indoor unit communication addresses setting

CAUTION! FAIL TO DO THIS, THE UNIT WILL NOT WORK.

1. There are two methods to set the communication address

A. Use the remote controller (default status in first installation).

B. Use dip switches on the indoor unit PCB.

2. Address setting procedure when using the remote controller.

A. Set the addresses only after the successful installation of the refrigerant pipes and connecting cables, and open all the stop valves;

B. Please confirm that the indoor units and the outdoor unit in the same system use the same power source;

C. Power on the units, but put all the indoor units in the status of STANDBY;

D. Please note that the address must be set as following:

Indoor unit that connect to valve A, the address must be 1;

Indoor unit that connect to valve B, the address must be 2;

Indoor unit that connect to valve C, the address must be 3;

Indoor unit that connect to valve D, the address must be 4;

E. Example: set unit A to address 1.

Continuously press the emergency switch for about 15 seconds, the buzzer will sound 4 times (PI PI PI PI) and then leave go of the switch. At this time, the indoor unit has entered the address setting procedure. But the LED board is blank.

F. Use the controller to turn on the indoor unit. At this time, the controller should be changed from OFF to ON, and then the TIMER LED flashes once. That is to say, the address setting is enabled.

G. Press the button "SLEEP" on the controller, the times you press it stands for the address you want to set, detailed as following:

Press button "SLEEP" once, the address is "1", and the TIMER LED flashes once;

Press button "SLEEP" twice, the address is "2", and the TIMER LED flashes twice;

Press button "SLEEP" three times, the address is "3", and the TIMER LED flashes three times;

Press button "SLEEP" four times, the address is "4", and the TIMER LED flashes four times;

H. Use the remote controller to turn off the unit, At this time, the controller should be changed from ON to OFF, and the unit will exit the address setting procedure, the address will be memorized.

The LED board will always display the address of this indoor unit until the system be powered off.

I. If you want to change the address, please repeat the above steps from E to G.

J. After setting all the addresses, please power off the system and then power on again. Otherwise

the system will not start to work. K. Once the addresses are successfully set, please do not change it any

3. Address setting procedure when using the DIP switches SW01 and SW02.

A. The DIP switches SW01 and SW02 are on the indoor unit PCB.

B. Before carrying out the address setting work, the system must be powered off.

C. Take off the front panel and the filters, then take off the flaps and also the front cover, disconnect the swing motor connectors from the PCB and then take out the lower part of the PCB.

D. Change the position of DIP 1 of SW01 from OFF to ON, if fail to do this, the addresses set by SW02 will not work.

E. Use SW02 to set the addresses as following (DO NOT CHANGE OTHER DIP SWITCHES):

■ Installation Manual of Room Air Conditioner

SW01	SW02	INDOOR UNIT ADDRESS																																																
<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr> <tr><td>■</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table> ON OFF	1	2	3	4	5	6	7	8	■																<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td>■</td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table> ON OFF	1	2	3	4	5	6	7	8						■											1
1	2	3	4	5	6	7	8																																											
■																																																		
1	2	3	4	5	6	7	8																																											
					■																																													
	<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td>■</td><td></td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table> ON OFF	1	2	3	4	5	6	7	8						■											2																								
1	2	3	4	5	6	7	8																																											
					■																																													
	<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td>■</td><td>■</td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table> ON OFF	1	2	3	4	5	6	7	8						■	■										3																								
1	2	3	4	5	6	7	8																																											
					■	■																																												
	<table border="1"> <tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td>■</td><td>■</td><td></td></tr> <tr><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr> </table> ON OFF	1	2	3	4	5	6	7	8						■	■										4																								
1	2	3	4	5	6	7	8																																											
					■	■																																												

How to check the addresses?

When finish all the above works, please power off and power on again to the whole system but set all the indoor units in STANDBY. Then continuously press the emergency switch until you hear the buzzer sound 5 times(Pi Pi Pi Pi Pi), and then the LCD displayboard Press any key on the remote controller, it will exit the address checking procedure.

TROUBLE SHOOTING	FAILURE CODE (TIMER LED OF INDOOR RECEIVER BOARD FLASHES TIMES)	POSSIBLE REASONS
Faulty temperature sensor Tai	ONCE *	Sensor disconnected, or broken, or at wrong position, or short circuit
Faulty temperature sensor Tc1	TWICE *	Sensor disconnected, or broken, or at wrong position, or short circuit
Faulty temperature sensor Tc2	3 TIMES *	Sensor disconnected, or broken, or at wrong position, or short circuit
Faulty temperature sensor Tm	4 TIMES *	Sensor disconnected, or broken, or at wrong position, or short circuit
Faulty EEPROM on indoor unit PCB	5 TIMES	Faulty indoor unit PCB
Abnormal communication between indoor and outdoor unit	6 TIMES *	Wrong connection, or the wires be disconnected, or wrong address setting of indoor unit
Indoor unit address repeated	9 TIMES	Wrong setting of indoor unit address
Faulty indoor unit fan motor	11 TIMES	Fan is blocked, or the terminal is disconnected from the PCB, or faulty indoor unit PCB
Faulty driver of indoor unit fan motor	12 TIMES	Faulty indoor unit PCB
Malfunction on outdoor unit	20 TIMES	Check the outdoor unit failure code

NOTE!

1. Please contact the installers or distributors when trouble happens to repair it.
2. Turn the power off and power on again, if the failure code recurs, please inform the franchiser.
3. Failure codes marked with * are resumable.

HAIER GROUP

Qingdao Haier Air Conditioner Electric Co., Ltd.

Address: Haier Garden, Qianwangang Road, Economic Development Zone,
Qingdao, Shandong 266555, P.R.China

Web Site: <http://www.haier.com>



Большая библиотека технической документации
<http://splitoff.ru/tehn-doc.html>
каталоги, инструкции, сервисные мануалы, схемы.