

user guide

R11HG/E



Большая библиотека технической документации
<http://splitoff.ru/tehn-doc.html>
каталоги, инструкции, сервисные мануалы, схемы.

R11HG/E

There's one model R11HG/E ,for hereinafter type:MSQ4I-07HRDN1, MSQ4I-09HRDN1, MSQ4I-12HRDN1, MSQ4I-18HRIN1 MST2I-07HRIN1, MST2I-09HRIN1, MST2I-12HRIN1, MST2I-18HRIN1

The below is R11HG/E remote controller

REMOTE CONTROLS AND THEIR FUNCTIONS

Mode select button

Each time you push the button, a mode is selected in a sequence that goes from AUTO, COOL, DRY, HEAT (cooling only type without), FAN ONLY and back to AUTO.

Fan speed button

This button is used for selecting fan speed. Each time you push the button, a fan speed is selected in a sequence that goes from AUTO, LOW, MED, HIGH, and back to AUTO.

ON/OFF button

Push the button to start operation, push the button again to stop operation.

Temperature button

- ▲ : The set temperature is increased to 30 C
- ▼ : The set temperature is decreased to 17 C



REMOTE CONTROLS AND THEIR FUNCTIONS

