

URV SYSTEM

INVERTER K Series

PLUS Series

The Compiled Sheets of Installation Work Inspection



Большая библиотека технической документации http://splitoff.ru/tehn-doc.html каталоги, инструкции, сервисные мануалы, схемы.


How to apply this information

- Search for an essential point to check referring to Contents first.
- 2) When an applicable page is found, specify OK/NG and enter the date and person checked in the respective column, copying the page to bring it to the work place.
- 3) If the check result is NG, correct the problem first. After correction, check and judge again entering the result.
- 4) Pascal is mainly applied to the pressure unit. To read the pressure in kg/cm², refer to Appendix (1) Pressure Conversion Table.
- 5) When the equipment is large-sized and equipped with multiple systems, apply Appendix (2) Check List, copy the list required to enter the check result in the applicable column and keep it in place.
- 6) When conducting test run after installation, apply Appendix (3) VRV Operation Check List to conduct a positive and effective checking.
- ★) Application of this check list will be able to reduce failures in operation and assure users of more reliability of equipment.


Contents

[A] Arrangement with constructor	
[A-1] Sleeve & insert work	1
[B] Indoor unit installation	
[B-1] Selection of installation location	2
[B-2] Required space around indoor unit	3
[C] Refrigerant piping work	
[C-1-(1)] Flaring, Proper application of tools (1)	4
[C-1-(2)] Flaring, Proper application of tools (2)	5
[C-2] Flare connection	6
[C-3] Brazing and Nitrogen gas replacement method	7
[C-4] Flange connecting work	8
[C-5] Pipe bending work	
[D] Refrigerant pipe connection	
[D-1-(1)] Protection cover for pipe (1)	9
[D-1-(2)] Protection cover for pipe (2)	10
[D-2] How to apply REFNET joint and header	11
[D-3] Installing REFNET joint and header	12
[D-4-(1)] Heat insulation for refrigerant pipes (1)	13
[D-4-(2)] Heat insulation for refrigerant pipes (2)	
[E] Drain piping	
[E-1] Basic items	15
[E-2] Collection pipe, flexible pipe and pipe support	16
[E-3] Application of clamp metal and final drain test	17
[E-4] Connection to vertical pipe	18
[E-5] Mounting blind plug	18
[F] Duct installation	
[F-1] Sound attenuation and heat insulation	19
[F-2] Flexible duct installation	20
[G] Electric wiring work	
[G-1] Checking control wiring	21
[G-2] Restriction on distance of control wiring	22
[G-3] Restriction on control wiring	23
[G-4] Restrictions on control wiring for connecting devices	24
[G-5] Mismatching connection of control wiring	25

[H]	Outdoor unit installation	
	[H-1] Making concrete foundation	. 26
	[H-2] Selection of installation location	. 27
	[H-3] Installation on terrace or ground	28
	[H-4] Types of foundation	. 29
[1]	Air-tight test	
	[I-1] Flushing	. 30
	[I-2] Conducting of air-tight test	. 31
[J]	Vacuum drying	
	[J-1] Selection of vacuum pump and vacuum drying actual data	. 32
[K]	Additional refrigerant charging	
	[K-1] Calculation of additional refrigerant charging amount (For K series)	. 33
[L]	Decorative panel installation	
	[L-1] Maintaining levelness of decorative panel	. 34
[M]	Air-conditioning system diagram	
	[M-1] Organizing air-conditioning system list and control wiring system diagram	. 35
٧	RV PLUS Series	
[N]	Switch setting for outdoor units	
	[N-1] Switch setting meeting the number of outdoor units	. 37
[0]	Outdoor unit installation	
	[O-1] Installation order of individual outdoor unit (In case that a function unit is equipped)	38
[P]	Additional refrigerant charging	
	[P-1] Calculation of additional refrigerant charging amount	. 39
	Appendix	
Δn	pendix	
Λh	(1) Pressure unit conversion table	40
	(2) Simultaneous check list for plural-system	
	(3) VRV system operation check list	





	(B) Indoor unit installation			
No.	(B-1) S	Selection of installation location Check Items	OK/NG	Checked by
1	Is there any gradient oposition?	or distortion with the unit installation		
	 Leave a gap at least 3cm from the surface of ceiling facing. 	Leave a gap of at least 3cm (leave pleanty To froom) Surface of ceiling facing		
	 Maintain the gradient of the horizontal surface within ±1°. 	Surface of ceiling facing		
	 Align to the joint line of ceiling materials. 	Indoor unit		
		(V0961)		




	(C) Refrigerant piping work					
	(C-1-(1)) Flaring, Proper application of tools (1)					
No.	Check Items	OK/NG	Checked by			
1	Is the pipe cutter used correctly?					
	Do not use high speed motor driven cutter, etc.					
2	Is the cut face deburred with a file?					
	 Deburr and flatten the cut face with a file. In this work, make the cut face down to prevent chips from entering. 					
3	Is the inside burr removed with reamer?					
	Check if chips remain inside pipe after removing inside burrs.					

	Check Date	/ .				
	(C) Refrigerant piping work					
	(C-1-(2)) Flaring, Proper application of tools (2)					
No.	Check Items	OK/NG	Checked by			
1	Is the lubricant applied after finishing of cut surface?					
	Apply refrigerating machine oil on both surfaces of flare. R-22 SUNISO R-407C Synthetic oil					
	R-407C Synthetic oil					







Is not the pipe section deformed?

• Be careful not to deform pipe due to bending work.

A buckling or a crack at this side may be generated.

Pipe may be deformed even it doesn't buckle.


Normal section (Non ellipse)

No.

1

	(D) Refrigerant pipe connection				
1	(D-1-(1)) Protection cover of pipe (1)				
No.	Check Items	OK/NG	Checked by		
1	Is pipes stored properly? (For coiled pipe)				
	 Making a table with plywood is the best way for storage of refrigerant pipes. Wooden bars or blocks can be also used for the alternatives. Store the pipes on a little upper level than the floor level to prevent moisture and dust from being caught on the pipe. 				
2	Is pipes stored properly? (For straight pipe)				
	Install stop bars at both sides of the pipe rack to prevent pipe from falling down. Stopper Assembly rack				
3	Are pipe ends put protection covers?				
	• Caps are put on the pipe ends at the time of delivery. It is forgettable to put caps at the pipe ends when storing the pipe after partially used.				

	(D) Refrigerant pipe connection					
	(D-1-(2)) Protection cover of pipe (2)					
No.	Check Items	OK/NG	Checked by			
1	Are pipe ends put protection covers when installing pipes through wall?					
	 Since construction site is dusty with concrete powder, soil, or sand, if bare pipes are passed through the hole without protection caps, dusts enter into the pipe definitely. 					
	Covering of pipe ends Through hole Outdoors					
	Pipe end protection with vinyl tape					
	Open end PVC tape Squeeze flat Bring tape back to starting point Tape round pipe again (V0969)					
2	Is protection to close pipe end during piping work conducted?					
	 Be sure to close pipe end to prevent foreign matters (moisture, dirt, sand or dust) from entering into the pipe even for short period of leaving the pipe in the air. 					
	Copper pipe Brazing area (V0968)					




	(D) Refrigerant pipe connection				
	(D-3) Installing REFNET joint and header				
No.	Check Items	OK/NG	Checked by		
1	Is the position of joint connection is proper?				
	 When installing refrigerant pipes horizontally, the refrigerant pipes can be inclined within 30°up and down. 				
	 When installing refrigerant pipes vertically, the refrigerant pipes should not be inclined, and must be installed vertically. 				
	Horizontal line View as seen from A Install within 30 angle (V1086)				
2	Is the position of header connection proper?				
	 Install REFNET header horizontally. Do not allow installing vertically. 				
	For gas pipe Field pipe Field pipe Field pipe Field pipe Field pipe For liquid line pipe For liquid line pipe For liquid pipe For l				

	(D) Refrigerant pipe connection				
	(D-4-(1)) Heat insulation for refrigerant pipes (1)				
No.	Check Items	OK/NG	Checked by		
1	Is heat insulation properly installed just after the equipment are connected?				
	 Sealing pad is provided with the unit as standard accessory. Install the sealing pad properly. 				
	Insulation for fitting (for liquid type) Clamp (attached) Liquid pipe Gas pipe Sealing pad (attached) Insulation for fitting (for gas line) (attached) 3PA60998-14P-5				
2	Are the specifications and thickness of heat insulation materials appropriate? • When applying polyurethane foam to the insulation materials, the thickness shown in the following table is required.				
	Pipe size Thickness of insulation material				
	6.4mm~25.4mm 10mm or more				
	28.6mm~38.1mm 15mm or more				
3	Is not the following imperfection conducted?				
	 Both liquid and gas pipes without heat insulation themselves installed with bundle by insulation materials. Pipe joint section has not been insulated. This part has not been insulated. 				

	(D) Refrigerant pipe connection (D.4.(2)) Heat insulation for refrigerant pipes (2)			
No.		OK/NG	Checked by	
No.	Check Items Is insulated refrigerant pipe supported properly? Pipe outside diameter 6.35 - 9.52mm 12.7mm or more Pitch of pipe support 1.2m or less 1.5m or less Copper pipe Insulation Metal support bracket	OK/NG	Checked by	
	Provide 1 or 2 supports on each floor module Vertical band Lample of Vertical band Provide 1 or 2 supports on each floor module Covered copper pipe			

Check Date	
Check Date	


	(E) Drain piping				
	(E-1) Basic items				
No.	Check Items	OK/NG	Checked by		
1	Does drain pipe have sufficient gradient? Gradient of at least 1/100 (Icm / Im)				




(E) Drain piping (E-3) Application of clamp metal and final drain test **Check Items** No. OK/NG | Checked by 1 Are the attached covering materials and clamp metal applied in good manner? • Mount clamp metal after taping the pipe. • Tighten the clamp metal so that the screw head protrudes by 4 mm. Clamp metal Clamp metal Large sealing pad (attached) (attached) Drain hose 4 mm or less Tape (White) (V1008) (V1009) • Cover the clamped section with covering materials. 2 Is the drainage conducted properly? Water inlet Portable pump • Fill 2500 cc water from the water inlet with a portable pump. Water inlet lid Turn on power supply and set to the test run mode. Selecting "FAN" and pressing ON button, the fan and drain pump will 🗸 Refrigerant piping (V1012) 220V-240V single Electric parts box lid (V1013) Access opening > start to operate. Open an access panel and make sure if the drain water reduces. Access opening lid (V1014)

(F) Duct installation			
No.	(F-1) Sound attenuation and heat insulation Check Items	OK/NG	Checked by
1	When installing steel plate ducts, are canvas ducts provided on the both sides to prevent vibration?	Orano	onconcu by
	Suspension bolts Canvas duct Canvas duct		
2	Glass wool of 25 m/m thickness is applied normally. When installing square ducts, the steel ducts are generally wrapped with glass wool insulation pad and bound with wire mesh. Welding Anchor rivet		


(F) Duct installation (F-2) Flexible duct installation No. **Check Items** OK/NG Checked by 1 Are the materials of ducts selected properly? • High heat insulation duct must be used on the air supply side. Standard duct can be used on the air suction side. Standard type insulation type ■Structure ■ Structure PVC film PVC film Glass wool (24 kg/m³, 13 mm thickness) Glass wool (24 kg/m3, 25 mm thickness) PVDC film Special -woven cloth Glass wool (24 kg/m3, 13 mm thickness) Steel wire (\$\phi 1.0 to 1.2 mm) Steel wire (\$1.0 to 1.2 mm) Application Application Applies when installing the unit in ambient air of high Applies mainly when installing the unit inside the ceiling of temperature and humidity to supply cool air, mainly to the middle floor in houses and buildings. inside of ceiling in new buildings constructed of reinforced Applies to ventilation system. concrete, inside of ceiling on the rooftop of existing buildings inside of ceiling in restaurants, factories generating much heat, etc. Optimum to apply to ambient air of high humidity. • Applies to low-temperature discharge air (10°C) 2 Is the connection work to apparatus conducted properly? Flexible duct, straight, 10 meters long (standard) K-FDS Finishing procedure for cut surface ■ Cutting method Cut the outer film and glass wool using a cutter knife. Use a cutting pliers or the like to cut wires. ■ Finishing cut surface (Use cut surface finishing kit K-FDSKP shown on Page 79.) Told back from the cut section. (Step I) Glass wool Flexible duct Special non-woven cloth 2 Push the duct into Step II flange. 3 Securely wind with adhesive tape Reset the folded cut section and tighten with a plate band (K-FDQP). (Step III) Finally wind on the band with heat insulator (K-FDSKP) to finish. (Step IV)





	Check Date			
	(G) Electric wiring work			
	(G-4) Restrictions on control wiring for connecting devices			
No.	Check Items	OK/NG	Checked by	
1	Is the number of connected device with one control system		-	
	within the specified number shown in the below table?			
	HANDLING EQUIPMENT NUMBER			
	Device Numbers Numbers controllable connectable (Groups) (Units)			
	Remote 64 16			
	Central remote 2 64 × 2 128			
	Unified ON/ Q 16 × 8 129			
	1 04 120			
	4 100 4 128			
	Data station 1 64 128			
	Master station $1 \begin{array}{c} 64 \times 4 \\ (256) \end{array} \begin{array}{c} 128 \times 4 \\ (512) \end{array}$			
	— (250) (512)			

(G) Electric wiring work (G-5) Mismatching connection of control wiring **Check Items** No. OK/NG Checked by 1 Does the refrigerant piping system coincide with the control system? • An example of faultily exchanged piping connection Faulty connection of the control wiring to another system's circuit. -pipes - cables Outdoor unit Indoor Indoor Indoor unit unit unit unit An example of checking mismatching wiring [1] Conduction = OK! [2] No conduction = NG Piping and wiring are not coincident possibly! Short Indoor (Refrigerant piping) Outdoo Outdoo Outdoo Short (B) Indoor unit




	(H) Outdoor unit installation					
	(H-2) Selection of installation location					
No.	Check Items	OK/NG	Checked by			
1	When installing outdoor unit on rooftop, is enough space provided around the unit?					
	 When the height of barrier wall is 1500 mm on the front side and 500 mm on the intake side, basically leave a space of 500 mm or more apart on the front side and 300 mm or more apart on the intake side. When the height of barrier wall exceeds 1500 mm and 500 mm respectively, provide additional horizontal distance by 1/2 of height exceeding 1500 mm on the front side and by height exceeding 500 mm on the intake side. 					
2	When installing outdoor unit on terrace, is any measure taken for the confined area?					
	 When installing outdoor unit at confined terrace, it should be considered to take some measures to install ducts. (Static pressure in the ducts should be 3 mmH₂O or less.) Adjust the air velocity discharged from the duct to 5 to 8 meters/second, and the intake air velocity coming through decorative blind to 1.6 meters/second or less. 					

(H) Outdoor unit installation					
(H-3) Installation on terrace or ground					
Check Items	OK/NG	Checked by			
Is the standard for mounting on ground observed?					
 When L ≥ 1 m, N ≥ M When L < 1 m, K ≤ M 					
Is the standard for mounting on terrace observed? • No restriction when $L \ge 3$ m When $L < 3$ m, an air discharge duct is required. (The head-loss of the duct should be 3 m/mH ₂ O or less.) Air discharge duct (to prevent short circuiting)					
	(H-3) Installation on terrace or ground Check Items Is the standard for mounting on ground observed? ● When L ≥ 1 m, N ≥ M When L < 1 m, K ≤ M Installation under the eaves Is the standard for mounting on terrace observed? ● No restriction when L ≥ 3 m When L < 3 m, an air discharge duct is required. (The head-loss of the duct should be 3 m/mH₂O or less.)	(H-3) Installation on terrace or ground Check Items OK/NG Is the standard for mounting on ground observed? • When L ≥ 1 m, N ≥ M When L < 1 m, K ≤ M Installation under the eaves Is the standard for mounting on terrace observed? • No restriction when L ≥ 3 m When L < 3 m, an air discharge duct is required. (The head-loss of the duct should be 3 m/mH₂O or less.)			

	(H) Outdoor unit installation				
	(H-4) Types of foundation				
No.	Check Items	OK/NG	Checked by		
1	Is not the foundation such as only putting concrete blocks at four corners?				
	RSX(Y)8K·10K RSX8KA·10KA				
	Avoid foundation that only supports the unit at four corners.				
	 A continuous footing as shown in the above figure is applicable while a mat foundation is recommendable. 				
	Tay Foundation bolt position (
	 In the above mentioned case, the anchor bolts should be located inside the shaded area. 				
2	Have the fixtures for transportation removed from compressor legs? If wild birds, etc. may enter the unit, block up the space (Stop portion) above the accessory pipe after refrigerant piping work. (When taking out the pipe) Attached pipe Compressor Fitting for loading Figure 2 (V0657) It is recommendable to close the connection port with proper material to prevent wild birds from entering and nesting inside the unit.				

(I) Air-tight test					
(I-1) Flushing					
No.	Check Items	OK/NG	Checked by		
1	Has the entire system been flushed using a nitrogen gas?				
	 Conduct flushing at the final stage of piping work to remove foreign particles and moisture that remained in the pipes. 				
	Work flow 1 From indoor unit to the shaft on individual floor 2 Vertical pipes inside each shaft 3 From each shaft to outdoor unit installed on rooftop				
	 Procedure Increase the pressure approximately to 0.5MPa* through a pressure reducing valve using a nitrogen gas. Make sure that the nitrogen gas comes out through the joint section other than flare connection. Close the flared section with the palm of the hand. When the pressure becomes high, release the hand quickly. Close the flared section with the palm of the hand again. When the pressure becomes high, move the hand quickly as well. During the flushing process, place a waste cloth at the pipe end, check the content and amount of the removed foreign particles, and repeat the flushing process until the foreign particles are released thoroughly. When completing the flushing process, provide covering plug, etc. to close the pipe end. (if the connection and vacuum drying is not conducted immediately just after the completion of the flushing process.) 				
	★ See Appendix for the unit conversion.				



Check Date / / (J) Vacuum drying (J-1) Selection of vacuum pump and vacuum drying actual data No. **Check Items** OK/NG Checked by 1 Is the achievable degree of vacuum of pump selected correctly? • Degree of vacuum should be in the shadowed area of below figure. Unit Standard atmospheric pressure Perfect vacuum Gauge Pressure kg/cm² 0 -1.033 Absolute Pressure kg/cm²abs 1.033 0 Torr Torr 760 0 0 Micron Micron 760000 cmHg 0 cmHg 076 hPa Pa 1013.33 0 Degree of vacuum must be within the range expressed by 0 Torr 5 Torr 760 Torr 0 Pa 667 Pa 1013.33 hPa 78 cmHg 75.5 cmHg 0 cmHg Perfect vacuum Vacuum target value Standard atmospheric pressure [Vacuum drying actual data] Is the degree of vacuum after 3 hours or more pump OK · NG operation -755 mmHg or lower? Is the degree of vacuum kept without change for 1 hour or OK · NG more after pump stopped?

		<u> </u>	
	(L) Decorative panel installation		
	(L-1) Maintaining levelness of decorative panel		
No.	Check Items	OK/NG	Checked by
1	Is decorative panel installed horizontally?		
	 Since insufficient tightening of screws causes poor workmanship shown below, securely tighten the screws. 		
	Air leakage from ceiling surface Dirt generation Dewing, dew drooping		
2	Is there any clearance left between the ceiling surface and decorative panel?		
	 Should a clearance be left between the ceiling surface and decorative panel even by tightening the screws, re-adjust the installation height of the main unit of indoor unit. 		
	Mount decorative panel without any clearance between the ceiling surface.		
	Advice on a single point —		
	The installation height of the main body of indoor unit can be adjusted from a hole provided at a corner of decorative panel with decorative panel installed in a range that the adjustment does not affect the levelness of indoor unit, drain piping, etc.		

(M) Air-conditioning system diagram (M-1) Organizing air-conditioning system list and control wiring system diagram No. **Check Items** OK/NG Checked by 1 Have the following "System List" and "Control Wiring System Diagram" been organized? [Example] System List (2) (1)(5) Outdoor unit Indoor unit Centralized Option Model Remote Model Local System Location name control control setting to install name name Field setting, etc. (symbol) grouping group No. Cooling/Heating change over Indoor Low noise mode FXYC32K 2F01 1-00 Office on 2nd floor FXYC63K 2F02 Α (1-00)RSXY10k Individual FXYC40K 2F03 (1-00)Seguential startu (PAC1) Defrosting Early Sequential startu No. FXYC63K 2F04 1-01 В FXYC50K 2F05 Reception on 2nd floo В (1-01)Cooling/Heating FXYC32K lesign room on 3rd floo 3F01 С 1-02 change over Indoor FXYC40K 3F02 С (1-02)RSXY10K Low noise Individual (PAC2) FXYC40K 3F03 (1-02)С FXYC50K 3F04 D 1-03 [Example] Control Wiring System Diagram RSXY10k RSXY10K RSXY8K PAC2 No.0 No.1 No.2 1-01 (7) Centralized group No. 1-00 (4) System name 2F04 2F03 C50K C40K S50K S32K S40K C40K C50K (3) Model name H63K H40K В C Α E F To central contol panel 2nd floor reception room (2nd floor office) (4th floor office)

INIV PLUS Series

Only peculiar problems of Plus series are described in this chapter. As for installation of indoor unit and setting of switch, refrigerant piping and drain piping, control system relating with central remote control, etc. are the same as K series. Therefore, relevant sheet in the previous chapter can be selected and used for those of Plus series.

(N) Switch setting for outdoor units (N-1) Switch setting meeting the number of outdoor units **Check Items** No. OK/NG Checked by 1 When the outdoor unit is equipped with function unit, has the number of outdoor units set through a switch in advance? Setting on function unit BC3K (cooling only), BL3K (cooling and heating) and BR3K (heat recovery) are equipped with outdoor units number setting switch SS3. Set the number to the specified number using the SS3. 3-unit setting 2-unit setting SS3 SS3 Setting on outdoor unit Constant speed unit is equipped with switch SS2. Set to "3" or "2" using the SS2. 3-unit setting Constant Constant Inverter speed type 1 speed type 2 type **Function** unit SS3 2 3 OUT 2 3 001 NO. SS2 NO. • The capacity of constant speed unit (1) should be larger than that of (2) 2-unit setting Inverter Constant speed type type Function unit SS3 OUT



(O) Outdoor unit installation (O-1) Installation order of individual outdoor unit (In case that a function unit is equipped) OK/NG Date Checked by No. **Check Items** Are installation order and piping connection with function unit of inverter unit and constant speed unit correct? The inverter unit should be installed at the furthest position from the function unit. Function unit Inverter Constant speed outdoor unit 2 Constant speed outdoor unit outdoor unit 1 Pipes do not cross each other To indoor unit Function unit Constant speed Constant speed Inverter outdoor unit 2 outdoor unit outdoor unit 1 Example where pipes cross each other Pipes cross each other To indoor unit Since the order of piping connection port in the function unit has been set, piping is forced to cross each other when the inverter unit installed close to the function unit.

Appendix

(1) Pressure unit conversion table

Absolute pressure		Gauge pressure MPa
kg/cm²	kg/cm ² G	(Mega Pascal)
41	40	3.92
40	39	3.82
39	38	3.73
38	37	3.63
37	36	3.53
36	35	3.43
35	34	3.33
34	33	3.24
33	32	3.14
32	31	3.04
31	30	2.94
30	29	2.84
29	28	2.75
28	27	2.65
27	26	2.55
26	25	2.45
25	24	2.35
24	23	2.26
23	22	2.16
22	21	2.06
21	20	1.96
20	19	1.86
19	18	1.77
18	17	1.67
17	16	1.57
16	15	1.47
15	14	1.37
14	13	1.27
13	12	1.18
12	11	1.08
11	10	0.98
10	9	0.88
9	8	0.78
8	7	0.69
7	6	0.59
6	5	0.49
5	4	0.39
4	3	0.29
3	2	0.20
2	1	0.10
1	0	0
0	-1	-0.1

[Notes]

sake.

- 1)This table is prepared based on the ratio of **1** kg/cm² = **0.0981MPa** and rounded off to the second decimal place.
- 2)Gauge pressure originally equals to (Absolute pressure value) 1.033 kg/cm².
 However, (Absolute pressure value)
 1.0 kg/cm² is applied for convenience's
- 3)Further, in the air conditioning industry, the MPa is rounded off to the first decimal place for the practical use in many cases. This is not wrong in use and convenient to read since 1/10 of kg/cm² becomes equal to MPa, and does not cause any serious problem in the practical use.
- 4)This manual describes many examples making the kg/cm² value 1/10 to use as MPa. However, refer to this table when more accurate pressure conversion is required.

(2) Simultaneous check list for plural-system.

Project name:		
System name:	(Model name) Outdoor unit:	Indoor unit:
	(Installation site) Outdoor unit:	Indoor unit:

Item	Symbol	No.	Page	Preparati	on prior to	operation	Remarks
	Symbol	INO.	Page	OK/NG	Date	Name	Remarks
A Arrangement with	A-1	1	1				
constructor		2					
B Installation of	B-1	1	2				
indoor unit	B-2	1	3				
C Refrigerant piping	C-1-(1)	1					
work		2	4				
		3					
	C-1-(2)	1	5				
	C-2	1	6				
		2					
	C-3	1	7				
	C-4	1	8				
	C-5	1					
D Piping connection	D-1-(1)	1	9				
work		2					
		3					
	D-1-(2)	1	10				
		2					
	D-2	1	11				
	D-3	1	12				
	-	2					
	D-4-(1)	1	13				
		2					
	D 4 (0)	3					
E. Dunin minimu	D-4-(2)	1	14				
E Drain piping	E-1	1	15				
	E-2	1	16				
	E-3	1	17				
	F 4	2	40				
	E-4	1	18				
E Duct work	E-5	1	40				
F Duct work	F-1	1	19				
	F 0	2	20				
	F-2	1	20				
		2					

Item	Symbol	No.	Dogo	Preparati	on prior to	operation	Remarks
nem	Symbol	INO.	Page	OK/NG	Date	Name	Remarks
G Electrical work	G-1	1	21				
		2					
	G-2	1	22				
	G-3	1	23				
	G-4	1	24				
	G-5	1	25				
H Installation of	H-3	1	28				
outdoor unit		2					
	H-4	1	29				
		2					
I Air tight test	I-1	1	30				
	I-2	1	31				
J Vacuum drying	J-1	1	32				
K Refrigerant	K-1	1	33				
additional charging		2					
L Installation of decoration panel	L-1	1	34				
M Air conditioning system line	M-1	1	35				
Plus series							
N Outdoor unit switch	N-1	1	37				
O Installation of outdoor unit	O-1	1	38				
P Refrigerant additional charging	P-1	1	39				

(3) VRV system operation check list

Date of inspection	year	month	day
Date of supply	year	month	day
Date of delivery	year	month	day

User name	System name	
-----------	-------------	--

Outdoor unit

	Series	Division unit	Installation site	Model name	Serial No.
K, KA					
	No function unit	Master unit			
Р	(New KA series)	Slave unit			
L	I (Conventional K ⊢	Function unit			
U		Constant speed outdoor unit 1			
S		Constant speed outdoor unit 2			
	Series)	Inverter unit			

Indoor unit

No	Installation site	Model name	Serial No.	Group No.	No	Installation site	Model name	Serial No.	Group No.
1					16				
2					17				
3					18				
4					19				
5					20				
6					21				
7					22				
8					23				
9					24				
10					25				
11					26				
12					27				
13					28				
14					29				
15					30				

Field setting

Cool/heat mode switching (Setting mode 1)		Cool/heat mode switching setting (SS1)			Low noise input			sequential startup		
Individual	Unified master	Unified slave	Indoor Outdoor		Provide	ed	None	Provided	None	
	Tc Te				Defrost			Refrigerant additional charging amount		
Normal	High	Low	Normal	High	Low	Normal	High	Low		kg

Company name	Inspector

System name

■ Prior to power ON

	Check item	Check method	Standard (Guide line)	Actual measurement	Judgemer						
	Breaker capacity	Visual check	Specified capacity	OK/NG							
Б	Refrigerant piping line	With gas leakage detector	No leakage	OK/NG							
Function unit	Terminal connection section	With driver, etc.	No loosening	OK/NG							
	Refrigerant piping line	With gas leakage detector	No leakage	OK/NG							
outdoor unit	Heat exchanger	Visual check	No clogging, no damage	OK/NG							
90	Terminal connection section	With driver, etc.	No loosening	OK/NG							
ţ	Insulation of fan motor	with 500 V megger	1 MΩ or more	MΩ							
0 /	Insulation of compressor	with 500 V megger	1 MΩ or more	ΜΩ ΜΩ							
<u>≥</u>	Installation condition	Visual check	No air short circuit, etc.	OK/NG							
<u>-</u>	Refrigerant piping line	With gas leakage detector	No leakage	OK/NG							
	Heat exchanger	Visual check	No clogging, no damage	OK/NG							
'n	Terminal connection section	With driver, etc.	No loosening	OK/NG							
oop	Insulation of fan motor	with 500 V megger	1 MΩ or more	ΜΩ							
ont	Insulation of compressor	with 500 V megger	1 MΩ or more	ΜΩ ΜΩ							
STD outdoor unit	Installation condition	Visual check	No air short circuit, etc.	OK/NG							
	Refrigerant piping line	With gas leakage detector	No leakage	OK/NG							
jŧ(Heat exchanger	Visual check	No clogging, no damage	OK/NG							
ı.	Terminal connection section	With driver, etc.	No loosening	OK/NG							
outdoor unit (2)	Insulation of fan motor	with 500 V megger	1 MΩ or more	MΩ							
ont	Insulation of compressor	with 500 V megger	1 MΩ or more	MΩ MΩ							
STD	Installation condition	Visual check		OK/NG							
တ	Installation condition	Visual Crieck	No air short circuit, etc.								
		With gas leakage detector		Room 1 OK/NG Room 2 OK/NG Room 3 OK/NG Room 4 OK/NG Room 5 OK/NG	-						
	Refrigerant piping line		No leakage	Room 6 OK/NG Room 7 OK/NG Room 8 OK/NG Room 9 OK/NG Room 10 OK/NG	-						
				Room 11 OK/NG Room 12 OK/NG Room 13 OK/NG Room 14 OK/NG Room 15 OK/NG	-						
-				Room 16 OK/NG Room 17 OK/NG Room 18 OK/NG Room 19 OK/NG Room 20 OK/NG	-						
				Room 21 OK/NG Room 22 OK/NG Room 23 OK/NG Room 24 OK/NG Room 25 OK/NG	-						
				Room 26 OK/NG Room 27 OK/NG Room 28 OK/NG Room 29 OK/NG Room 30 OK/NG	-						
	Air filter	Visual check	No clogging, no damage	Room 1 OK/NG Room 2 OK/NG Room 3 OK/NG Room 4 OK/NG Room 5 OK/NG	-						
				Room 6 OK/NG Room 7 OK/NG Room 8 OK/NG Room 9 OK/NG Room 10 OK/NG	5						
				Room 11 OK/NG Room 12 OK/NG Room 13 OK/NG Room 14 OK/NG Room 15 OK/NG	3						
				Room 16 OK/NG Room 17 OK/NG Room 18 OK/NG Room 19 OK/NG Room 20 OK/NG	6						
				Room 21 OK/NG Room 22 OK/NG Room 23 OK/NG Room 24 OK/NG Room 25 OK/NG	6						
				Room 26 OK/NG Room 27 OK/NG Room 28 OK/NG Room 29 OK/NG Room 30 OK/NG	6						
				Room 1 OK/NG Room 2 OK/NG Room 3 OK/NG Room 4 OK/NG Room 5 OK/NG	ì						
				Room 6 OK/NG Room 7 OK/NG Room 8 OK/NG Room 9 OK/NG Room 10 OK/NG	ì						
	Heat	Visual check	No clogging, no damage	Room 11 OK/NG Room 12 OK/NG Room 13 OK/NG Room 14 OK/NG Room 15 OK/NG	ì						
	exchanger	Visual Criccic		Room 16 OK/NG Room 17 OK/NG Room 18 OK/NG Room 19 OK/NG Room 20 OK/NG	6						
j≓				Room 21 OK/NG Room 22 OK/NG Room 23 OK/NG Room 24 OK/NG Room 25 OK/NG	3						
Indoor unit				Room 26 OK/NG Room 27 OK/NG Room 28 OK/NG Room 29 OK/NG Room 30 OK/NG	3						
8				Room 1 $M\Omega$ Room 2 $M\Omega$ Room 3 $M\Omega$ Room 4 $M\Omega$ Room 5 $M\Omega$							
입				Room 6 MΩ Room 7 MΩ Room 8 MΩ Room 9 MΩ Room 10 MΩ							
	Insulation of	With 500 V	1 MO or mars	Room 11 $M\Omega$ Room 12 $M\Omega$ Room 13 $M\Omega$ Room 14 $M\Omega$ Room 15 $M\Omega$	-						
	fan motor	megger	1 M Ω or more	Room 16 MΩ Room 17 MΩ Room 18 MΩ Room 19 MΩ Room 20 MΩ							
				Room 21 $M\Omega$ Room 22 $M\Omega$ Room 23 $M\Omega$ Room 24 $M\Omega$ Room 25 $M\Omega$							
				Room 26 $M\Omega$ Room 27 $M\Omega$ Room 28 $M\Omega$ Room 29 $M\Omega$ Room 30 $M\Omega$							
				Room 1 M Ω Room 2 M Ω Room 3 M Ω Room 4 M Ω Room 5 M Ω	-						
				Room 6 M Ω Room 7 M Ω Room 8 M Ω Room 9 M Ω Room 10 M Ω	-						
	Insulation of	With 500 V	4.140	Room 11 $M\Omega$ Room 12 $M\Omega$ Room 13 $M\Omega$ Room 14 $M\Omega$ Room 15 $M\Omega$							
	aux. heater	megger	1 MΩ or more	Room 16 $M\Omega$ Room 17 $M\Omega$ Room 18 $M\Omega$ Room 19 $M\Omega$ Room 20 $M\Omega$	-						
	aux. Heatel	11109901			-						
					-						
				Room 26 M Ω Room 27 M Ω Room 28 M Ω Room 29 M Ω Room 30 M Ω	-						
				Room 1 OK/NG Room 20 K/NG Room 3 OK/NG Room 4 OK/NG Room 5 OK/NG							
	Inotallation		No oir obort	Room 6 OK/NG Room 7 OK/NG Room 8 OK/NG Room 9 OK/NG Room 10 OK/NG							
	Installation	Visual check	No air short	Room 11 OK/NG Room 12 OK/NG Room 13 OK/NG Room 14 OK/NG Room 15 OK/NG	-						
	condition		circuit, etc.	Room 16 OK/NG Room 17 OK/NG Room 18 OK/NG Room 19 OK/NG Room 20 OK/NG	-						
				Room 21 OK/NG Room 22 OK/NG Room 23 OK/NG Room 24 OK/NG Room 25 OK/NG	-						
		1		Room 26 OK/NG Room 27 OK/NG Room 28 OK/NG Room 29 OK/NG Room 30 OK/NG	il						

System name

■ During operation

	Check item	Check method	Standard (Guide line)	Actual measurement Judge									
Function	Power supply voltage	With tester	Rated voltage ± 10 %	ý V									
	Main power voltage	With tester	Rated voltage ± 10 %	R-S	V	S-T	V	R-T	V				
	Operation circuit voltage	With tester	Rated voltage ± 10 %	V									
	Fan rotating direction	Visual check	Rotates in normal direction	OK/NG									
INV outdoor unit	Fan noise, vibration	Acoustic check, etc.	No abnormal noise nor vibration										
	Fan operation current	With clamp meter		A									
	Suction air temperature	Thermometer	Temperature difference, when cooling: 9 to 11 °C	°C									
	Discharge air temperature	Thermometer	when heating: 2 to 3.5 °C	°C									
outd	Compressor suction pressure	Pressure gauge		INV		MPa*	STD		MPa*				
	Compressor discharge pressure	Pressure gauge		INV	MPa*		STD		MPa*				
	Compressor operating current	With clamp meter	Difference between phases: within 1 A	INV	Α		STD		А				
	Compressor operation frequency	With clamp meter			Hz								
	Suction pipe temperature	Thermometer	3~15°C	INV	°C		STD		°C				
	Discharge pipe temperature	Thermometer	85~105°C	INV	°C		STD		°C				
	Crank case heater	Touching check	Becomes warm	INV		OK/NG	STD		OK/NG				
	Main power voltage	With tester	Rated voltage ± 10 %	R-S	V	S-T	V	R-T	V				
	Operation circuit voltage	With tester	Rated voltage ± 10 %	V									
	Fan rotating direction	Visual check	Rotates in normal direction	OK/NG									
iit (1)	Fan noise, vibration	Acoustic check, etc.	No abnormal noise nor vibration										
	Fan operation current	With clamp meter		A									
l n	Suction air temperature	Thermometer	Temperature difference, when cooling: 9 to 11 °C	°C									
8	Discharge air temperature	Thermometer	when heating: 2 to 3.5 °C	°C									
outdoor unit	Compressor suction pressure	Pressure gauge		STD1		MPa	STD2		MPa				
STD	Compressor discharge pressure	Pressure gauge		STD1	MPa		STD2		MPa				
S S	Compressor operating current	With clamp meter	Difference between phases: within 1 A	STD1	А		STD2		А				
	Suction pipe temperature	Thermometer	3~15°C	STD1	°C		STD2		°C				
	Discharge pipe temperature	Thermometer	85~105°C	STD1	°C		STD2		°C				
	Crank case heater	Touching check	Becomes warm	STD1		OK/NG	STD2		OK/NG				
	Main power voltage	With tester	Rated voltage ± 10 %	R-S	V	S-T	V	R-T	V				
	Operation circuit voltage	With tester	Rated voltage ± 10 %	V									
	Fan rotating direction	Visual check	Rotates in normal direction	OK/NG									
(8)	Fan noise, vibration	Acoustic check, etc.	No abnormal noise nor vibration										
	Fan operation current	With clamp meter		A									
outdoor unit	Suction air temperature	Thermometer	Temperature difference, when cooling: 9 to 11 °C	°C									
	Discharge air temperature	Thermometer	when heating: 2 to 3.5 °C	°C									
ontc	Compressor suction pressure	Pressure gauge		STD1	MPa		MPa STD2		MPa				
STD	Compressor discharge pressure	Pressure gauge		STD1		MPa	STD2	MP					
	Compressor operating current	With clamp meter	Difference between phases: within 1 A	STD1		Α	STD2		Α				
	Suction pipe temperature	Thermometer	3~15°C	STD1		°C	STD2		°C				
	Discharge pipe temperature	Thermometer	85~105°C	STD1		°C	STD2		°C				
	Crank case heater	Touching check	Becomes warm	STD1	OK/NG		STD2 OK/N		OK/NG				

 $[\]bigstar$ For unit conversion of pressure, refer to the annex.

System name

■ During operation

	Check item	Check method	Standard (Guide line)	Actual measurement										Judgement
Indoor unit	Power supply voltage	With tester	Rated voltage ± 10 %	Room 1	V	Room 2	V	Room 3	٧	Room 4	V	Room 5	V	
				Room 6	V	Room 7	V	Room 8	٧	Room 9	V	Room 10	V	
				Room 11	V	Room 12	V	Room 13	٧	Room 14	V	Room 15	V	
				Room 16	V	Room 17	V	Room 18	٧	Room 19	V	Room 20	V	
				Room 21	V	Room 22	V	Room 23	٧	Room 24	V	Room 25	V	
				Room 26	V	Room 27	V	Room 28	٧	Room 29	V	Room 30	V	
	Suction air temperature	Thermometer	Temperature difference: when cooling, 9 to 13 °C when heating, 15 to 20 °C	Room 1	°C	Room 2	°C	Room 3	°C	Room 4	°C	Room 5	°C	
				Room 6	°C	Room 7	°C	Room 8	°C	Room 9	°C	Room 10	°C	
				Room 11	°C	Room 12	°C	Room 13	°C	Room 14	°C	Room 15	°C	
				Room 16	°C	Room 17	°C	Room 18	°C	Room 19	°C	Room 20	°C	
				Room 21	°C	Room 22	°C	Room 23	°C	Room 24	°C	Room 25	°C	
				Room 26	°C	Room 27	°C	Room 28	°C	Room 29	°C	Room 30	°C	
	Discharge air temperature			Room 1	°C	Room 2	°C	Room 3	°C	Room 4	°C	Room 5	°C	
				Room 6	°C	Room 7	°C	Room 8	°C	Room 9	°C	Room 10	°C	
				Room 11	°C	Room 12	°C	Room 13	°C	Room 14	°C	Room 15	°C	
				Room 16	°C	Room 17	°C	Room 18	°C	Room 19	°C	Room 20	°C	
				Room 21	°C	Room 22	°C	Room 23	°C	Room 24	°C	Room 25	°C	
				Room 26	°C	Room 27	°C	Room 28	°C	Room 29	°C	Room 30	°C	
용	Fan rotation direction	Visual check	Rotates in normal direction	Room 1	OK/NG	Room 2	OK/NG	Room 3	OK/NG	Room 4	OK/NG	Room 5	OK/NG	
<u>=</u>				Room 6	OK/NG	Room 7	OK/NG	Room 8	OK/NG	Room 9	OK/NG	Room 10	OK/NG	
				Room 11	OK/NG	Room 12	OK/NG	Room 13	OK/NG	Room 14	OK/NG	Room 15	OK/NG	
				Room 16	OK/NG	Room 17	OK/NG	Room 18	OK/NG	Room 19	OK/NG	Room 20	OK/NG	
				Room 21	OK/NG	Room 22	OK/NG	Room 23	OK/NG	Room 24	OK/NG	Room 25	OK/NG	
				Room 26	OK/NG	Room 27	OK/NG	Room 28	OK/NG	Room 29	OK/NG	Room 30	OK/NG	
	Fan noise, vibration	Acoustic check, etc.	No abnormal noise nor vibration	Room 1	OK/NG	Room 2	OK/NG	Room 3	OK/NG	Room 4	OK/NG	Room 5	OK/NG	
				Room 6	OK/NG	Room 7	OK/NG	Room 8	OK/NG	Room 9	OK/NG	Room 10	OK/NG	
				Room 11	OK/NG	Room 12	OK/NG	Room 13	OK/NG	Room 14	OK/NG	Room 15	OK/NG	
				Room 16	OK/NG	Room 17	OK/NG	Room 18	OK/NG	Room 19	OK/NG	Room 20	OK/NG	
				Room 21	OK/NG	Room 22	OK/NG	Room 23	OK/NG	Room 24	OK/NG	Room 25	OK/NG	
				Room 26	OK/NG	Room 27	OK/NG	Room 28	OK/NG	Room 29	OK/NG	Room 30	OK/NG	
	Fan operation current	With clamp meter		Room 1	Α	Room 2	Α	Room 3	Α	Room 4	Α	Room 5	Α	
				Room 6	A	Room 7	Α	Room 8	Α	Room 9	A	Room 10	Α	
				Room 11	A	Room 12	Α	Room 13	A	Room 14	A	Room 15	Α	
				Room 16	A	Room 17	А	Room 18	A	Room 19	А	Room 20	Α	
				Room 20	A	Room 22	Α	Room 23	Α	Room 24	A	Room 25	Α	
				Room 26	A	Room 27	Α	Room 28	A	Room 29	A	Room 30	Α	

